How to Paint Wire Mesh

Last updated 24 April 2026

Below you will find step by step instructions on how to paint metal wire mesh.

OVERVIEW


- **Experience Required:** Beginner
- **Tools Required:** Protective Gloves, Spray Paint, Wire Cutters
- **Materials Required:** Cardboard/Old Newspaper, Welded Wire Mesh

Step 1) Prepare the Work Area




- Lay out a discardable piece of cardboard to simplify cleanup.
- Collect all required tools and materials.
- Pick your desired mesh colour and select compatible spray paint.

Step 2) Trim the Wire Mesh



- Use wire cutters to trim the mesh to your desired dimensions.
- Wear protective gloves to avoid cuts from sharp edges.

Step 3) Apply Spray Paint




- Follow instructions on the spray paint can.
- Apply an even coat of paint over the wire mesh.

Step 4) Paint the Reverse Side



- Flip the mesh and apply another even layer of spray paint.

Step 5) Allow to Dry



- Let the painted wire mesh dry completely.
- Congratulations, you're finished!

Tips and Tricks for Painting Wire Mesh

- Opt for spray paint that is designed for metal surfaces to ensure better adhesion and durability.
- Paint in a well-ventilated area or outdoors to avoid inhaling fumes.
- Apply several light coats of paint rather than one heavy coat to prevent drips and ensure even coverage.
- Allow ample drying time between coats to achieve a smooth finish.
- Test the spray paint on a small section of the wire mesh to see how it adheres before committing to the entire piece.

Dos and Don’ts for Painting Wire Mesh

Do:

- Always wear gloves and a mask to protect yourself from paint fumes and sharp edges.
- Ensure the wire mesh is clean and free of dust or grease before painting.
- For better paint adhesion, consider applying a metal primer before painting.
- Spray in a consistent, even motion to avoid streaks and clumps.
- If painting outdoors, choose a day with mild weather and low humidity.

Don’t:

- Avoid handling or moving the mesh before it is completely dry to prevent smudges.
- Never spray paint in confined areas without proper ventilation.
- Skipping the preparation steps can lead to poor paint adhesion and an uneven finish.
- Holding the spray paint can too close to the mesh can result in drips and runs.
- Cover surrounding areas with newspapers or a drop cloth to prevent overspray from damaging other surfaces.

Further reading

- How To Cut Wire Netting: A guide to cutting wire mesh of different thicknesses.
- DIY Wire Mesh Lamp Shade: Learn how to create a lamp shade, using painted wire mesh.