GABION MATTRESS Installation

Gabion mattress

What You'll Need:

- PVC coated
- tying wire Geotextile Gabion stone (optional)

Wire cutters

Protective gloves

- **Prepare the Foundation**



Remove any debris and make sure the surface is even and firmly compacted to create a solid foundation for the cage.


Add Geotextile (Optional)

For added stability and erosion control,

geotextile over the prepared surface

before placing the gabion mattresses.

you may choose to lay down a



secured to the base using a full length of tying wire.

Assemble Gabion Mattress

The two sides and diaphragm(s) are


Unfold the gabion mesh on flat, solid

The base, ends (front, back, and lid) are

constructed from a single continuous

surface.

piece of material.



Secure the tying wire to the top corners of the panels, then weave it down along the edges.

Use double and single loops spaced

approximately 10cm apart along the

Alternatively, use C-rings to fasten the

Secure the Diaphragm

wire mesh openings.

panels.

tying wire.

x 80mm).

Connect the diaphragm(s) to the side

panels and secure them firmly using

Fill with Stone

Start filling the gabion mattress with

stones of suitable size (minimum 80mm

Close the Lid

In the process of gabion mattress

installation, fold the lid panel over the

filled basket, ensuring it fits securely

Attach the Lid

over the stones.

Make sure the lid panels are tightly

secured to the gabion mattress by

C-rings, following the same method

fastening them with tying wire or

used for the edges.