



## POULTRY FENCING INSTALLATION With T-Posts




### THINGS YOU'LL NEED

- [Poultry fencing](#)
- [T Posts](#)
- Tape measure
- Post driver or mallet
- [Cable ties](#)
- Spirit level
- String
- [Pegs](#)
- [Tensioning wire](#) (optional)
- Plier (optional)
- Spade
- Cement (optional)


**INSTRUCTIONS****Step 1: Mark Area**

Mark a straight line for the fence between the two posts at each end.

**Step 2: Measure Post Distance**


Use a tape measure to indicate the post locations 2 -3m apart.

To enhance stability, shorten the distance between your fence posts.

**Step 3: Install End Posts**


Drive the end posts 50cm into the ground by using a post driver or mallet.

Ensure that the holes of the posts face each other to maintain consistent alignment.




#### Step 4: Check for Same Height

Fasten a piece of string between the end posts, then check that they have been installed at the same height by using a tape measure.




#### Step 5: Check for Straightness

Employ a spirit level to ensure that the posts have been installed perfectly straight.



#### Step 6 (Optional): Set in Concrete

To achieve a stronger and more secure fence, set your posts in concrete by digging a 50cm hole and pouring cement for the post to rest in.




### Step 7: Install Middle Posts

To install middle posts, replicate steps 3-5.

Ensure that the posts are facing in the same direction and are installed both straight and at the same height.


You can also secure the middle posts with concrete for added strength.



### Step 9 (Optional): Install Tension Wire

When working with light weight mesh, you may want to attach a tension wire between the end posts to prevent any sagging.


Wrap the tension wire around the hole of the end posts and secure it by twisting the wire's end with a plier.



### Step 10: Secure Mesh to End Post

Secure the mesh to the end post by using cable ties, which can be threaded through the pre-drilled holes in the post.


You can add more cable ties by enclosing the entire post.



### Step 11: Pull Taut

Pull the mesh taut and then secure it to the second post using cable ties. Make sure not to pull too tightly.

Repeat this process until you reach the end post.



### Step 12 (Optional): Secure to Tension Wire

If you've set up a tension wire, secure the mesh to it using cable ties, spacing them approximately 30-45 cm apart.

