



WELDED WIRE MESH INSTALLATION With Wooden Posts




THINGS YOU'LL NEED

- Welded wire mesh
- Wooden posts
- Pliers
- Hammer
- Wire cutters
- Staples or Cable ties
- Pegs (additional)
- Spade (optional)
- Cement (optional)


INSTRUCTIONS**Step 1: Mark the Post Location**

Specify the post locations while maintaining a spacing of 2-2.5m between each post.


**Step 2: Dig Holes**

Dig a hole for the posts, ensuring that the depth of the hole is approx. one-third of the post's length.

Use a spirit level to verify that the posts are perfectly upright.

**Step 3: Cement Posts In (Optional)**


After filling the holes with concrete, position your posts within the concrete.



Step 4: Attach Mesh to End Post


Take sufficient mesh to cover the distance between the initial two posts.

Secure the mesh to the posts using staples or cable ties at 15cm intervals.



Step 5: Repeat Step 4

Proceed with securing the remaining section of the mesh by following the process described in step 4.



Step 6: Attach Mesh to Last Posts

Attach the mesh to the last post to complete the fencing installation.