

HOW TO INSTALL GABION CLADDING Installation Without Support Posts




THINGS YOU'LL NEED

- Shovel
- Spirit Level
- Concrete
- Industrial Clamp Plate
- <u>Gabions</u>
- Gabion Stone
- <u>Helicals/Tying wire</u>
- Lintel (Optional)
- Angle Section (Optional)
- Clamp bar (Optional)

WireFence

INSTRUCTIONS




Email: info@wirefence.co.uk

Telephone: 0330 124 3556

11-15 Barlow Road, Levenshulme, Manchester, M19 3DH

WireFence




Email: info@wirefence.co.uk

Telephone: 0330 124 3556

11-15 Barlow Road, Levenshulme, Manchester, M19 3DH





Telephone: 0330 124 3556

11-15 Barlow Road, Levenshulme, Manchester, M19 3DH



ANATOMY OF A TYPICAL INSTALLATION

