



PVC WIRE NETTING INSTALLATION With Extra Security




THINGS YOU'LL NEED

- PVC coated wire netting
- <u>Tensioning wire</u> (optional)
- <u>Radisseur</u> (optional)
- Pliers
- Hammer
- Wire cutters
- Wooden posts
- <u>Staples</u>
- <u>Cable ties</u>
- <u>Pegs</u>
- Spade
- Cement (optional)

INSTRUCTIONS








Email: info@wirefence.co.uk

Telephone: 0330 124 3556

11-15 Barlow Road, Levenshulme, Manchester, M19 3DH







Step 11: Cover the Trench

Apply 5cm of soil or mulch to conceal the outer flap.

Optional: Add a layer of concrete into the trench to enhance security against digging.