## **HOW TO STOP DOG FROM** Jumping Over a Fence What You'll Need:

## Staples Cable ties

- Brackets Screws

Dog fencing


- Marker

- Tape measure Hammer Plier


Protective gloves

Wire cutter

- **Calculate Nr of Brackets**



Mark Bracket Placement A2



Use wood screws to attach the brackets

Continue this process until the entire

Shorten Mesh A4

in the marked locations.

area is complete.

entire length of the

Select a mesh roll with a height that matches the length of the brackets. If your mesh roll is taller, measure the length of the bracket and cut along the marked line using wire cutters. **Secure Mesh to Brackets** 

Attach the bottom of the mesh to the

wood using staples placed at 15 cm

A7 Complete & Inspect

Ensure you check the netting

thoroughly for any weak spots to

eliminate gaps or wiggle room.

1.8 - 2m

Use cable ties to secure the mesh to the

If there are no pre-drilled holes, loop

the cable ties around the entire bracket


Attach Mesh to Wood A6

pre-drilled holes in the brackets.

instead.

intervals.

Calculate Nr of Brackets



Use a tape measure to mark where the

Fix Brackets

brackets should be attached to the

fencing.

**B4** Cut Mesh

Choose a mesh roll with a height

cut using wire cutters.

matching the length of the brackets.

If the mesh roll is taller, measure the

length of the bracket, mark the line, and

Attach Mesh to Brackets **B5** 

entire length of the

Continue this process until you

Use wood screws to attach the brackets

in the marked locations.

complete the whole area.

If there aren't any, loop the cable ties around the entire bracket instead.

pre-drilled holes in the brackets.

Use cable ties to attach the mesh to the

**Secure Mesh to Fence** Use cable ties or wire ties, spaced 15 cm apart, to secure the bottom of the mesh to the fence.

Finish Fence Run & Inspect B7

Ensure thorough inspection of the

netting for any weak spots.