


HOW TO REPAIR Chain Link Fence

What You'll Need:


- Chain link fence
- Stretcher bars
- Hog rings
- Wire cutters
- Fence stretcher
- Pliers
- Tape measure
- Protective gloves

1 Identify the Damaged Section




Begin the process of how to repair chain link fence by identifying the damaged section of the fence.

2 Remove Attachments



If the section is connected to a top or bottom tension wire, untie or cut it first.


3 Cut One Strand



On one side of the damaged area, cut a single wire strand using wire cutters.

Since the fence is under tension, you won't be able to untwist the wire at this stage.


4 Untwist Strand Other Side



On the other side, untwist the wire strand by hand, since the fence is not under tension now.


Set this strand aside.

5 Half Diamonds



Keep half diamond ends on both sides so the replacement section can be connected later.

6 Measure Out Material




Ensure the replacement material matches the size and wire gauge of the fence.

Measure enough material to cover the gap, leaving a little extra.

Alternatively, use the damaged section as a guide, but cut the replacement slightly longer.


7 Untwist Wire from Roll



Untwist a wire strand from the roll at the point where you want to cut the material to the required length.


You can reuse this strand in the next step.

8 Connect at One Side



Twist the removed wire strand to secure the replacement section to one side of the existing mesh.

9 Fabric May Sag



The mesh will sag without tension, so it's normal for the links to droop.

You won't be able to connect the other side until it is tightened.

10 Position the Two Bars

Position two stretcher bars at each end of the opening, making sure they are not placed in the end diamonds.

11 Pull Sections Together

In the process of how to repair chain link fence, use a stretcher tool to pull the two sections together.

12 Complete The Repair

Once aligned, weave in the saved wire strand to connect both sides and complete the repair.

13 Remove Tool and Bars

Once secured, remove the stretcher tool and tension bars.

14 Secure It Back

Secure the mesh back to the top and bottom tension wires using hog rings.

15 Finished Project

You're all set. The material is now repaired.